

AXMINSTER
PROProfessional

AP254TS

Table Saw Workstation & Additional Tables



Cert No: HW110LGE-30

Axminster Tool Centre Ltd
Axminster Devon
EX13 5PH UK
axminstertools.com

declares that the machinery described:-

Type	Table saw
Model	AP254TS

Signed



Andrew Parkhouse
Operations Director

Date: **29/08/2018**

EU Declaration of Conformity

This machine complies with the following directives:

2006/42/EC
06/42/EC - Annex I/05.2006
EN 60204-1:2006+A1+AC
EN 1870-19:2013

conforms to the machinery example for which the
EC Type-Examination Certificate No BM50416470
has been issued by **Harvey Industries Co., Ltd.**
at: 01 Building, No.68 Suyuan Road, Jiangning Economic & Technological Development Zone,
Nanjing 211100 China

and complies with the relevant essential health and safety requirements.

1. Foreword

This manual contains basic information for qualified operating staff and describes the surroundings and using ways of the machine for those it is intended. It contains also all necessary information for a correct and safe operating. The machine is equipped with various safety equipment protecting operator and machines well at usual technological using. These regulations, however, cannot sheet all other safety aspects. That is why operator must peruse and make sense of this manual before starting of machine use. Installation and operation mistakes will be foreclosed herewith.

Do not try to start the machine before having read all instructions manual delivered with the machine and understood every function and technique.

3. Machine Description

3.1 Technical parameters

Item		HW110LGE-30	HW110LGE-50
Product Dimensions	weight	260Kg (approx.)	
	length/width/height(mm)	1582x1100x1016	2090x1100x1016
	foot print(length/width)	508x508	
Electrical:	switch	magnetic with thermal overload protection	
Motor	type	TEFC capacitor start induction	
	horsepower/voltage/phase/amps	3HP-230V-1PH 12.8A	
	speed/cycle	2850 RPM/50HZ	
	power transfer	Triple V-belt Drive	
blade information	maximum blade diameter	250mm	
	ripping knife/spreader thickness	2.5mm	
	required blade body thickness	1.8-2.4mm	
	required blade kerf thickness	2.6-3.2mm	
	maximum width of Dado	15mm	
	blade tilt	left 0-45°	
	arbor size	30mm	
	arbor speed	4150 RPM(50Hz)	
	arbor bearings	sealed and permanently lubricated	
cutting capacities	maximum depth of cut at 90°	70mm	
	maximum depth of cut at 45°	50mm	
	maximum rip to right of blade-standard	750mm	1250mm
	maximum rip to left of blade	305mm	
Table informations	floor to table height	860mm	
	main table--length/width/thickness	512x685x48mm	
	distance front of table to center of blade	440mm	
	distance front of table to blade of maximum cut	310mm	
miter gauge information	miter gauge slot type	T-slot	
	miter gauge slot type-- width/height	19.05 ×9.525mm	
other information	paint	power coated	
	dust port size	100mm	

3.2 Feature Identification(Fig.1)




Fig.1

- | | |
|----|-------------------------|
| 1 | Left Extension Wing |
| 2 | Mitre Gauge |
| 3 | Blade Guard |
| 4 | Main table |
| 5 | Right Extension Wing |
| 6 | Fence |
| 7 | Rear Rail |
| 8 | Extension Table |
| 9 | Front Rail Tube |
| 10 | Blade Tilt Hand wheel |
| 11 | Dust Port |
| 12 | Table Tilt Scale |
| 13 | Blade Height Hand wheel |
| 14 | Motor cover |
| 15 | On/Off Switch |
| 16 | Leg(not shown) |

Remark:

The fence is not as shown, this model is equipped with a aluminium fence

The blade guard is not as shown, this model is equipped with a blade guard contain dust port

3.3 Intended Use

Table saw and the workpiece guide equipment supplied with it are intended to be used exclusively for the following purposes:

- Laminated and unlaminated board materials (e.g. chipboard, coreboard, MDF board, ...)
- Solid wood
- Gypsum plasterboard , Cardboard, Veneer with a suitable clamping device
- Dimensionally stable plastics (thermoset plastics, thermoplastics).Sawing these materials does not normally involve any risks in respect of dust, chips, and thermal degradation products.

Tools:

- The chosen saw blade must be suitable both for the specific work cycle and for the specific material.
- Only circular blades which are solid chrome vanadium (CV) or tungsten carbide tipped (TCT) and have a diameter of 250mm , arbor size 30mm,as well as a maximum width of 20mm are allowed for the main saw.
- Saw blades made of high-alloy high-speed steel (HSS) are not allowed to be used.
- Saw blades and their fixing devices shall conform to EN 847-1:2005.

Site of installation/use:

- The machine is not suitable for use outdoors, or in rooms that are subject to moisture or the risk of explosions.
- The intended use of the machine involves connection to a suitably dimensioned extraction system .
- Intended use also involves compliance with our specified operating, maintenance and repair conditions and the safety information contained in the operating instructions.
- The table saw may only be used, set up and

maintained by persons who are familiar with the machine and aware of the dangers.

● The pertinent accident prevention regulations as well as any other generally recognised technical safety and industrial medicine rules must be observed.

● Repair work must be carried out by our own customer service or by an organization that we have authorized. Only original spare parts are allowed to be used for this. we will assume no warranty for any damage that is caused by using non-original spare parts.

WARNING

The machine is prohibited to be used in a potentially explosive atmosphere!

3.4 Requirements of electrical power

List of the motor using & pre-wired voltage

Item	Motor
	3HP
	(2.2kW)
Voltage(V)	230V
Phase	1Ph
Freq.(Hz)	50Hz
Nominal current A	12.8A
Prewired	230V/1PH
Cords	3

Frequency

0.99 ~ 1.01 times of rated frequency (50 Hz , continuous working)

0.98 ~ 1.02 times of rated frequency(50Hz, short period working)

Harmonics

The sum of 2nd-5th distorted harmonic must not exceed 10% of RMS of voltage. An additional 2% of RMS of line voltage is allowed to for the sum of 6th-30th harmonic.

Unbalanced voltage

Neither Negative nor zero sequence components is allowed to exceed 2% of the positive sequence component.

Electrical protection

End user should provide protection device against overvoltage due to lightning and short-circuited protection device at the power supply.

Ingress Protection at the inlet of incoming power cable

The incoming method of incoming cable should ensure IP54 protection class when finishing installation on the spot.

3.5 Noise

3.5.1 Reference standards

The measurements of noise emission were conducted according to the EN ISO 11202 for the determination of sound pressure level at the operation positions. When the measured sound pressure levels at the operation positions exceed 85dB(A), the measurements of sound power levels were conducted according to EN ISO 3746.

3.5.2 Operating conditions

The operating conditions for noise measurement comply with Annex A of ISO 7960:1995.

3.5.3 Testing results

		NO LOAD	LOAD
L_{WA}		101.3	104.1
L_{PA}	Position A	84.7	88.5
	Position B	86.1	89.1
	Position C	77.0	79.8
Associated uncertainty		<i>K</i> = 4 dB	

Note: Background noise of measurement surrounding is 65.0dB (A).

The figures quoted are emission levels and are not necessarily safe working levels. Whilst there is a correlation between the emission and exposure levels, this cannot be used reliably to determine whether or not further precautions are required. Factors that influence the actual level of exposure of the workforce include the characteristics of the work room, the other sources of noise etc. i.e. the number of machines and other adjacent processes. Also the permissible exposure level can vary from country to country. This information, however, will enable the user of the machine to make a better evaluation of the hazard and risk.”

4. Safety Regulations

4.1 General Safety Instructions

1. KNOW YOUR MACHINE.

Read and understand the owners manual and labels affixed to the machine. Learn its application and limitations as well as its specific potential hazards;

2.GROUND THE MACHINE.

In the event of the electrical short, grounding reduces the risk of electrical short;

3. KEEP GUARDS IN PLACE.

Keep in good working order, properly adjusted and aligned;

4. REMOVE ADJUSTING KEYS AND WRENCHES.

Form habit of checking to see that keys and adjusting wrenches are removed from machine before turning it on;

5. KEEP WORK AREA CLEAN.

Cluttered areas and benches invite accidents. Make sure the floor is clean and not slippery due to wax and sawdust build-up;

6. AVOID DANGEROUS ENVIRONMENT.

Don't use machines in damp or wet locations or expose them to rain. Keep work area well lit and provide adequate surrounding work space;

7. KEEPCHILDREN AWAY.

All visitors should be kept a safe distance from work area;

8. MAKE WORKSHOP CHILD-PROOF.

With padlocks, master switches or by removing starter keys;

9. USE PROPER SPEED.

A machine will do a better and safer job when operated at the proper speed;

10. USE RIGHT MACHINE.

Don't force the machine or the attachment to do a job for which it was not designed;

11. WEAR PROPER APPAREL.

Do not wear loose clothing, gloves, neckties or jewelry (rings, watch) because they could get caught

in moving parts. Non-slip footwear is recommended. Wear protective hair covering to contain long hair. Roll up long sleeves above the elbows;

12. DON'T OVER REACH.

Keep proper footing and balance at all times;

13. MAINTAIN MACHINE WITH CARE.

Keep tools sharp and clean for best and safest performance. Follow instructions for lubricating and changing accessories;

14. DISCONNECT MACHINES.

Before servicing, when changing accessories or attachments;

15. AVOID ACCIDENTAL STARTING.

Make sure the switch is in the "OFF" position before plugging in;

16. USE RECOMMENDED ACCESSORIES.

Consult the manual for recommended accessories. Follow the instructions that accompany the accessories. The use of improper accessories may cause hazards;

17. NEVER STAND ON MACHINE.

Serious injury could occur if the machine tips over. Do not store materials such that it is necessary to stand on the machine to reach them;

18. CHECK DAMAGED PARTS.

Before further use of the machine, a guard or other parts that are damaged should be carefully checked to ensure that they will operate properly and perform their intended function. Check for alignment of moving parts, breakage of parts, mounting, and any other conditions that may affect its operation. A guard or other parts that are damaged should be properly repaired or replaced;

19. NEVER LEAVE MACHINE RUNNING UNATTENDED.

Turn power "OFF". Don't leave any machine running until it comes to a complete stop;

20. LIGHTING SHALL BE PROVIDED.

A adequate general or localised lighting shall be provided;

4.2 Specific Safety Instructions for Sliding Table Saw

1. ALWAYS USE A GUARD.

Always use a guard, splitter and anti-kickback fingers on all "thru-sawing" operations. Thru-sawing operations are those when the blade cuts completely through the work piece as in ripping or crosscutting.;

2. ALWAYS HOLD THE WORK.

Always hold the work firmly against the miter gauge or fence;

3. ALWAYS USE A PUSHSTICK OR PUSH BLOCKS.

Push blocks or push sticks shall be used when cutting small workpieces and in circumstances where it is necessary to push the workpiece against the fence;

4. NEVER.

Never perform any operations "free-hand" which means using your hands to support or guide the work piece. Always use either the fence or the miter gauge to position and guide the work piece;

5. NEVER.

Never stand or have any part of your body in line with the path of the saw blade;

6. NEVER REACH BEHIND.

Never reach behind or over the cutting tool with either hand for any reason;

7. MOVE THE RIP FENCE.

Move the rip fence out of the way when crosscutting;

8. DIRECTION OF FEED.

Feed work into the blade against the direction of rotation;

9. NEVER.

Never use the fence as a cut-off gauge when you are cross-cutting;

10. NEVER.

Never attempt to free a stalled saw blade without first turning the saw OFF;

11. PROVIDE ADEQUATE SUPPORT.

To the rear and sides of the table saw for wide or long work pieces;

12. AVOID KICKBACKS.

Avoid kickbacks (work thrown back towards you) by keeping the blade sharp, by keeping the rip fence parallel to the saw blade, by keeping the splitter and anti-kickback fingers and guard in place and operating, by not releasing work before it is pushed all the way past the saw blade, and by not ripping work that is twisted or warped or does not have a straight edge to guide along the fence;

13. AVOID AWKWARD OPERATIONS.

Avoid awkward operations and hand positions where a sudden slip could cause your hand to move into the spinning blade;

14. BLADE REQUIREMENTS.

Only correctly sharpened saw blades manufactured in accordance with the requirements of EN 847-1:2005 shall be used;

15. SPEED.

No saw blade shall be used where the maximum marked speed is lower than the maximum rotational speed of the saw spindle;

16. CHIP AND DUST.

The machine shall be connected to an external chip and dust extraction system;

The dust extraction equipment is to be switched on before commencing machining;

17. CHECK

Period check the brake function to make sure the stop time of the saw blade is less than 10s.

4.3 Residual risks

1. Take precautions to reduce the hazard of inhalation of harmful dusts (e.g. wearing a dust mask);
2. Wear ear protection to prevent hearing loss;
3. Always wear safety glasses. also use a face or dust mask if cutting operation is dusty;
4. Against the hazard of cutting when handling saw blades into the machine or doing maintenance;
5. Not to try removing chips whilst the saw blade(s) is (are) running and the saw unit(s) is (are) not in the rest position;
6. Not to try using the machine unless all of the guards and other safety devices necessary for machining are in good working order;

4.4 Safety equipment

A push block (**Fig.2**) and A push stick (**Fig.3**) must be used




Fig.2




Fig.3

WARNING

If the workpieces is less then 120mm,you must use the push stick to prevent your hands from getting too close to the saw blade.

Push block must be used to cut narrow workpieces and, when necessary, to push the workpiece against the fence, a push block can be easily made by the operator as **Fig.2**,

5. Installation of the machine

5.1 Transportation of machines

5.1.1 Transportation and store

The measures of anti-rust and shockproof should be taken during packing. The machine endures transportation and store in -25~55°C ambient temperature.

Be care of not making machine exposed to rain or damaging the packing during transportation and store.



WARNING

While transporting or handling the machine, be careful and let the activity be done by qualified personnel especially trained for this kind of activity!

While the machine is being loaded or unloaded, make sure that no person or subject gets pressed by the machine!

Select proper transportation device according to the weight of the machine.

Make sure the lifting capacity of transportation device is competent for the weight of the machine.

5.1.2 Transportation before unpacking

As standard, the machine is packed in a robust wooden box. **Fig.4** shows the tool can be used to transport the packing box.



Fig.4

5.2 Unpacking

Your machine was carefully packaged for safe transportation. remove the packaging materials from around your machine and inspect it. if you discover the machine is damaged, please immediately call Customer Service for advice.

Save the containers and all packing materials for possible inspection by the carrier or its agent. Otherwise, filing a freight claim can be difficult.

5.3 Safety measure before use & installation

It is important to maintain free area of 0.8 m around the machine, which is required for the working place. If any long material is machined, it is necessary to have a sufficient room in front of the machine as well behind it in the places of material input and output.

5.4 installation

Before beginning assembly, take note of the following precautions and suggestions

----- The machine is bolted to the pallet. Before attempting any of the assembly procedures remove all of the loose parts and hardware from the inside of the machine and unbolt the machine from the pallet.

----- **FLOOR:** This tool distributes a large amount of weight over a small area. Make certain that the floor is capable of supporting both the weight of the machine and the operator. The floor should also be a level surface. If the unit wobbles or rocks once in place, be sure to eliminate by using shims.

-----**WORKING CLEARANCES:** Take into consideration the size of the material to be processed. Make sure that you allow enough space for you to operate the machine freely.

-----**OUTLET PLACEMENT:** Outlets should be located close enough to the machine so that the power cord or extension cord is not in an area where it would cause a tripping hazard. Be sure to observe all electrical codes if installing new circuits and/or outlets.



WARNING

DO NOT assemble the machine until you are certain that the machine is not plugged in and the power switch is in the OFF position.

DO NOT connect the machine to the power source until the machine is completely assembled and you read and understand the entire User Manual.

5.4.1 Remove the shipping brace:

pull the switch out of the saw cabinet and remove the shipping brace as **Fig.5** ;



Fig.5: shipping brace location

5.4.2 motor cover install:

Install the door by inserting the door pins into the hinge sockets on the cabinet as **Fig.6**;



Fig.6: motor cover install

5.4.3 handwheel handle install:

Install the handle into the Blade Tilt & Height hand wheel as **Fig.7**.




Fig.7: hand wheel handle install

5.4.4 Extension wings install(Fig.8)

A. remove the screws from the ends of the main table;

B. inspect the extension wings and main table mating surfaces for burrs or foreign materials that may inhibit assembly;

C. the mating edges of the wings and the table must be clean, smooth, and flat, use a wire brush or file if necessary to clean up the edges, this step will ensure that the wings mount properly to the main table;

D. Attach the wings to the main table with the screws removed in step A;

E. Place the straightedge across the extension wings and main table to make sure that the table surface is flat;

.....If the outside end of extension wings tilts down Or up, use a strip of masking tape to shim the extension wing up Or down ;




Fig.8: Extension wings install

5.4.5 install the rail & fence

A. install the rear rail , front rail, tube, (extension table) as breakdown, Before tightening the fasteners,check to make sure the top edge of rear rail is flush with the lowest edge of both T-bolts, so the miter gauge will slide smoothly when installed later. as Fig.9




Fig.9: check the location of rear rail

B, Place the fence on the rails on the right hand side of blade as Fig.10-2 .

Note:make sure the cam foot contacts the cam on the fence lock handle before you place the fence on the rail, otherwise the fence will not lock into the rail tube. See Fig.10-1




Fig.10-1: Fence assembled




Fig.10-2: fence installed on rails

Remark:

The fence is not as shown, this model is equipped with a aluminium fence

C, checking fence parallelism(see Fig.11)

----Slide the fence along the rail , if it drags across the table, then adjust the foot at the rear of the fence to raise the fence off of the table just enough , so that the gap between the fence, and the table is even from front to back;

----Slide the fence up, against the right hand edge of the miter slot , and lock it in place ,examine how the fence line up with the miter slot;




Fig.11: checking fence parallelism

Note: *It's permissible for the back of the fence to pivot outward not more than 1/64" from being parallel to the blade. This creates a slightly larger opening between the fence and the blade, at the rear of the blade, to reduce the risk of workpiece binding or burning as it is fed through the cut. Many woodworkers intentionally set up their fence in this manner. Keep this in mind before adjusting your fence.*

D, Install the fence scale(see Fig.12)




Fig.12 Aligning rail tape with scale pointer.

Slide the fence up against the saw blade, and lock it in place;

place the front rail tape scale on the fence tube, make sure it is parallel with the tube, and the "0" end

is directly under the red line on the pointer window as shown; lightly mark the "0" location on the tube with a pencil, then remove the fence; peel the tape and carefully align the "0" mark on the scale with the pencil mark you made;

If you make a mistake, loosen the screws on the point window, slide the fence against the blade, adjust the pointer window , so the red line on the window is over the "0" mark on the tape, then secure the screws;

5.4.6 Install the switch

install the magnetic switch onto the bottom left hand side of the front rail using two M6-1x 12 hex bolts, 6mm lock washers, and 6mm flat washers, as shown in Fig.13




Fig.13: switch install

5.4.7 Install the blade

- A. Remove blade guard assembly & table insert.
- B. raise the arbor all the way up and set the blade angle at 0°.
- C. remove the arbor nut and arbor flange from the arbor, slide on the included 10" saw blade, making sure the teeth face the front of the saw, then install the arbor flange and arbor nut onto the blade.
- D. put on a pair of heavy leather gloves and use the included arbor wrenches to tighten the arbor nut (turn clockwise to tighten), as shown in **Fig.14**



Fig.14: Install the blade

5.4.8 install the blade guard and riving knife

- A. reinstall the insert, slide the knurled knob out (see **Fig.15**) and rotate it forward so it engages the upper bracket.




Fig.15:Knurled knob used

- B. slide the blade guard spreader all the way down into the block, then rotate the knurled knob so it

disengages the bracket and the locking pin engages the hole in the center of the spreader.

- C. give the spreader an upward tug to verify that it is locked the blade guard, when properly installed, look like **Fig, 16**




Fig.16: Blade guard installed.

- D. place a straightedge against the blade and the spreader. When properly aligned, the spreader/riving knife will be in the "alignment zone," shown in Fig.17 , and will be parallel with the blade.




Fig.17: alignment zone

After changing a saw blade, always check that the Riving knife or Blade Guard is correctly set!

1. riving knives shall be manufactured from steel with an ultimate tensile strength of 580 N mm⁻² or of a comparable material, have flat sides (within 0,1 mm per 100 mm) and shall have a thickness less than the width of cut (kerf) and at least 0,2mm greater than the saw blade plate. As **Fig.18**




Fig.18

Key:

e *iving knife thickness*

b *saw blade blade*

B *kerf(width of saw blade cut)*

2, The distance of the riving knife from the gear rim must be between 3mm and 8mm. measured radially through the centre of the saw spindle. As **Fig.19**




Fig.19

3. the highest point of the riving knife must be set beneath the topmost teeth.

WARNING

Check that saw blade clamping system is tight before operating the machine.

5.4.9 Connecting the extraction system

NOTICE

Dust collector device should be prepared by customer;

The dust extraction equipment is to be switched on before commencing machining;

The outlet diameter of is 100mm. **Fig.20**

Air current speed is 20m/s for vacuum suction dust emission index, When air current speed of dust collector device (in accordance with EN 12779:2004) is not lower than 20m/s, ensure machine can be normal exhausted. User must wear dustproof mask.

1. Required air flow:1500 m³/h;
2. Ensure pressure drop of each dust collector outlet carrying air current speed: 1100Pa
3. Wind speed of dust collector tube m/s: dry chips: 20m/s, water content is equal to18% wet chips: 28m/s.




Fig.20

5.4.10 Electrical installation

WARNING

1. Wiring should only be done by professional electricians. Always make sure the machine is properly earthed.

2. All wirings in the cabinets should be protected against direct contact to at least IP2X when finishing electrical installation.

3. All exposed conductive parts should be connected to the protective bonding circuit.

4. Close and lock the door of cabinets.

NOTICE

1. Enough space around the machine and the cabinets should be kept in order to maintain conveniently.

2. The machine should be installed in a workshop with good illumination and ventilation.

3. Over-voltage protection device should be provided by end user on spot.

Check that the voltage and frequency required by the machine, shown on the machine's name plate, correspond to the electric power supply voltage and frequency.

The circuit breaker shall be installed for supplying

electric power to this machine, in order to protect people against electrical shock due to indirect shock

Wiring:

Finish electrical connection according to the electrical drawings.

The wirings on the spot should refer to the requirements of Clause 13 (Wiring practices) of EN 60204-1:2006.

Checking:

After finishing wiring on the spot, check the following items at least:


Check the wirings of machine.

Check the direction of motors and change wiring if necessary.

Check the components for defects, such as loosening or damage.

Check the functions of safety devices

ELECTRICAL CONNECTIONS



6. Adjustment

NOTICE

Before operation, the machine should be carefully adjusted for best performance. Please make adjustment as following:

6.1 Blade Raising and Tilting Machine

To raise or lower the blade, loosen lock knob (A) As Fig 21 and turn the raising handwheel (B). When desired height is obtained, retighten lock knob. The blade should be raised 1/8" to 1/4" above the top surface of the material being cut. With hollow ground blades the blade should be raised to the maximum to provide chip clearance. To tilt the saw blade, loosen lock knob (C) and turn tilting handwheel (D). When desired angle is obtained, retighten lock knob. See **Fig.21**.




Fig.21

6.2 Adjusting Ripfence

1.The rip fence must be perfectly aligned with the table T-slot, to verify this, align the edge of the rip fence with the table T-slot and lower the locking lever (A)**Fig.22** to lock in into place. Check to see if the edge of the rip fence and the table T-slot are parallel. If they are not parallel, unlock the rip fence and turn it upside down. Adjust the set screws (A) as **Fig.23** in or out, verify your adjustment, repeat if

necessary.

2.The lock lever pressure can be adjusted by loosening the front lock nuts (B) as **Fig.22** and adjusting the set screws (C) the same amount, make sure the fence remains parallel with the table T-slot. Retighten lock nuts.

3.To set the fence perpendicular to the table, place a square on the table and against the side of the fence, loosen the top lock nuts (D) and adjust the setscrews (E) until the fence is perpendicular. Retighten lock nuts.

4.The pointer window (F) as Fig.22 position can be adjusted if needed, loosen pan head screws (G), reposition the pointer window and retighten pan head screws.




Fig.22




Fig.23

6.3 Aligning Table T-slot Parallel With Blade

1. The table T-slot must be aligned parallel with the blade. Using a combination square (A) as **Fig.24**, measure the distance from the back edge of the blade to the table T-slot. Pivot blade forward 180° and remeasure the distance using the exact same point on the blade. The difference between both measurements must be less than 0.2mm.

2. If an adjustment is necessary, loosen the screws (B) as **Fig.25** which fix to the table, make the needed adjustment until both measurements are equal or less than 0.2mm. and retighten the screws.




Fig.24




Fig.25: Adjust Trunnions to Align Blade and Miter Slot

6.4 Adjusting 45 and 90 Degree Positive Stops

The blade tilting mechanism of your saw is equipped with a positive stop at 45 and 90 degrees. To check and adjust these positive stops, proceed as follows:

1. Raise the saw blade to its maximum height.
2. Set the blade at 90 degrees to the table by turning the blade tilting hand wheel counterclockwise as far as it will go.
3. Place a square on the table and check to see if the blade is at a perfect 90 degree angle to the table.
4. If the blade is not at 90 degrees loosen lock nut (A) As Fig.26 and turn stop ring (B) in or out. The stop ring (B) should stop against the front trunnion bracket when the blade is at 90 degrees to the table. Recheck and adjust further if necessary. Retighten lock nut (A).




Fig.26: Adjust 90 degrees

5. If the 45 degree positive stop is not set properly, turn the same hand wheel clockwise as far as it will go and follow the same procedure using lock nut (C) As Fig.27 and stop ring (D). The stop bolt (D) should stop against the front trunnion bracket when the blade is at 45 degrees to the table. Recheck and adjust further if necessary. Retighten lock nut (C).




Fig.27: Adjust 45 degrees

6.5 Aligning Blade Guard Splitter or Riving Knife with Blade

The blade guard splitter and/or riving knife must be aligned with the blade. If not properly aligned, the splitter/riving knife will force the workpiece sideways during the cut, increasing risk of kickback. Place a straightedge against the blade and the splitter or riving knife and check for parallelism. If an adjustment is needed, the mounting position can be adjusted into alignment with the blade using the adjustment set screws (A) (see Fig.28)

1. Disconnect saw from power source.
2. Remove the table insert.
3. Loosen the upper and lower cap screws (B), then adjust the 4 set bscrews in or out until the alignment is perfectly parallel.
4. Reinstall the table insert.




Fig.28

6.6 Adjusting Mitre Bar Tightness

The miter bar can be adjusted so it fits more tightly in the miter slot.

To increase the miter bar tightness, tighten the set screws shown in **Figure 29**; to decrease the miter bar tightness, loosen the set screws.




Fig.29: Adjust Mitre Bar

7. Operations

7.1 Electrical Operation(*Fig.30*)

ON Button: Starts the motor (*see Figure 30*).

Safety Pin & Chain: When installed (*see Figure 30*), disables the ON Button to prevent accidental startup.

Emergency Stop/Reset Button: Turns machine OFF. Rotate clockwise to reset. (*see Figure 30*).




Fig.30

NOTICE

Turn the machine OFF: Insert the switch disabling pin through the green ON button, as shown in *Figure 30*.

7.2 Safety Precautions Before Operations

The operation of power tools involves a certain amount of hazard for the operator. Before attempting regular work we recommend you get the feel of operations using scrap lumber to check settings. Read entire instructions before you start to cut workpiece. Always pay attention to safety precautions to avoid personal injury.

7.3 Operation

Plain sawing includes ripping and crosscutting, plus a few other standard operations of a fundamental nature. The following methods feature safety. As with all power tools there is a certain amount of hazard involved with the operation and use of the tool. Using the tool with the respect and caution demanded as far as safety precautions are concerned will considerably lessen the possibility of personal injury. However, if normal safety precautions are overlooked or completely ignored, personal injury to the operator can develop. It is good practice to make trial cuts using scrap material when setting up you saw for operation.

7.4 Crosscutting

Crosscutting requires the use of the miter gauge to position and guide the work. Place the work against the miter gauge and advance both the miter gauge and work toward the saw blade, as shown in **Fig.31**. The miter gauge may be used in either table slot, however, most operators prefer the left groove for average work. When bevel cutting (blade tilted), use the table groove that does not cause interference of your hand or miter gauge with the saw blade guard. Start the cut slowly and hold the work firmly against the miter gauge and the table. One of the rules in running a saw is that you never hang onto or touch a free piece of work. Hold the supported piece, not the free piece that is cut off. The feed in crosscutting continues until the work is cut in two, then the miter gauge and work are pulled back to the starting point. Before pulling the work back it is good practice to give the work a little sideways shift to move the work slightly away from the saw blade. Never pick up any short length of free work from the table while the saw is running. A smart operator never touches a cut-off piece unless it is at least a foot long. Never use the fence as a cut-off gauge when crosscutting. Never use the mitre gauge in combination with the rip fence.




Fig.31

7.5 Ripping

Ripping is the operation of making a lengthwise cut through a board, as shown in **Fig.32**, and the rip fence is used to position and guide the work. One edge of the work rides against the rip fence while the flat side of the board rests on the table. Since the work is pushed along the fence, it must have a straight edge and make solid contact with the table. The saw guard must be used. The guard has anti-kickback fingers and a splitter to prevent the saw kerf from closing. Start the motor and advance the work holding it down and against the fence. Never stand in the line of the saw cut when ripping. Hold the work with both hands and push it along the fence and into the saw blade as shown in Fig. The work can then be fed through the saw blade with one or two hands.

When this is done the work will either stay on the table, tilt up slightly and be caught by the rear end of the guard or slide off the table to the floor. Alternately, the feed can continue to the end of the table, after which the work is lifted and brought back along the outside edge of the fence. The waste stock remains on the table and is not touched with the hands until the saw is stopped unless it is a large piece allowing safe removal.




Fig.32

8. Maintenance

This table saw requires very little maintenance other than minor lubrication and cleaning. The following sections detail what will need to be done in order to assure continued operation of your saw.

LUBRICATION

The table saw has sealed lubricated bearings in the motor housing and the arbor assembly, they will not require any additional lubrication. Use a wire brush to clean off the worm gears and trunnions and apply a white lithium grease to keep them lubricated

CLEANING

Cleaning the Model is relatively easy. Vacuum excess wood chips and sawdust, and wipe off the remaining dust with a dry cloth. If any resin has built up, use a resin dissolving cleaner to remove it.

After cleaning, treat all unpainted cast iron and steel with a non-staining lubricant.

Occasionally it will become necessary to clean the internal parts with more than a vacuum. To do this, remove the table top and clean the internal parts with resin/pitch dissolver or mineral spirits and a stiff wire brush or steel wool.

Make sure the internal workings are dry before using the saw again, so that wood dust will not accumulate. If any essential lubrication is removed during cleaning, re-lubricate those areas.

CHANGING BELTS

WARNING: MAKE SURE THE POWER CORD IS DISCONNECTED FROM THE POWER SOURCE!

1. Lower the blade completely, then open the motor access cover.
2. Loosen the hex nuts that secure the motor (see **Fig.33**) and raise the motor fully to remove tension on the V-belts. Roll the V-belts off of the arbor and motor pulleys.
3. While continuing to raise the motor, install a new

matching set of V-belts onto the pulleys, lower the motor to tension the V-belts, then tighten the hex nuts.

4. Close the motor access cover.




Fig.33

9. Trouble Shooting Guide

PROBLEM	SOLUTION
SAW WILL NOT START 1. Saw not plugged in. 2. Fuse blown or circuit breaker tripped. 3. Cord damaged.	1. Plug in saw. 2. Replace fuse or reset circuit breaker. 3. Have cord replaced by a certified electrician.
OVERLOAD KICKS OUT FREQUENTLY 1. Extension cord too light or too long. 2. Feeding stock too fast. 3. Blade in poor condition (dull, warped, gummed). 4. Blade binding due to misaligned rip fence. 5. Blade binding due to warped wood. 6. Low house current.	1. Replace with adequate size cord 2. Feed stock more slowly. 3. Clean or replace blade. 4. Check and adjust the rip fence. See rip fence instructions. 5. Select another piece of wood. 6. Contact your electrical company.
DOES NOT MAKE ACCURATE 45 AND 90 RIP CUTS 1. Positive stop(s) not adjusted properly. 2. Tilt angle pointer not set properly.	1. Check blade with square and adjust positive stop. 2. Check blade with square and adjust pointer to zero.
MATERIAL PINCHES BLADE WHEN RIPPING 1. Rip fence not aligned with blade. 2. Warped wood.	1. Check and adjust rip fence. 2. Select another piece of wood.
MATERIAL BINDS ON SPLITTER 1. Splitter not aligned correctly with blade kerf.	1. Check and align splitter with blade kerf.
SAW MAKES UNSATISFACTORY CUTS 1. Dull blade. 2. Blade mounted backwards. 3. Gum or pitch on blade. 4. Incorrect blade for work being done. 5. Gum or pitch on table causing erratic feed.	1. Replace blade. 2. Turn blade around. 3. Remove blade and clean with turpentine and steel wool. 4. Change the blade. 5. Clean the table with turpentine and steel wool.
BLADE DOES NOT COME UP TO SPEED 1. Extension cord too light or too long. 2. Low house current. 3. Motor not wired for correct voltage.	1. Replace with adequate size extension cord. 2. Contact your electric company. 3. Refer to motor and /or nameplate.
MACHINE VIBRATES EXCESSIVELY 1. Table not mounted securely to cabinet stand. 2. Stand is on uneven floor. 3. Damaged saw blade. 4. Bad V-belt(s). 5. V-belts not tensioned properly. 6. Bent pulley. 7. Improper motor mounting. 8. Loose hardware.	1. Tighten all mounting hardware. 2. Reposition on flat level surface. 3. Replace blade. 4. Replace V-belt(s). 5. Adjust V-belt tension. 6. Replace pulley. 7. Check and adjust motor mounting. 8. Tighten all nuts, bolts and set screws.
BLADE DOES NOT RAISE OR TILT FREELY 1. Sawdust or dirt in raising or tilting mechanisms.	1. Brush or blow out loose dust or dirt.

10. Parts List

Table Saw Body Breakdown




Table Saw Body Parts List

REF#	DERIPTION	QTY	REF#	DERIPTION	QTY
101	cabinet	1	132	set screw M5x12	8
102	cap screw M10*25	4	133	pan hd screw M5*16	2
103	lock washer 10	4	134	pan hd screw M5*20	2
104	flat washer 10	4	135	lock nut M5	2
105	scale	1	136	dado table insert	1
106	rivet nut M6x13.5	1	137	pan hd screw M5*12	3
107	cabinet plate	1	138	lock washer 5	3
108	pan hd screw M6*16	4	139	flat washer 5	3
109	big washer 5	4	140	limit plate	1
110	hook	3	141	set screw	2
111	rivet nut M5x12	3	142	tape	1
112	strain relief	1	143	tape	1
114	Motor cover	1	144	cap screw M8*30	6
115	Knob(CSA)/ cap screw M6*16(CE)	1	145	lock washer 8	6
116	barrier chip	1	146	flat washer 8	6
117	tape	2.1m	147-1	hairbrush	1
118	cleanout door	1	147-2	hairbrush	1
119	door latch	1	147-3	dust cover	1
120	knob	1	147-4	rivet nut M4	3
121	flat washer 8	1	148	pan HD screw M4*12	3
122	lock washer 8	1	149	lock washer 4	3
123	lock nut M8	1	150	flat washer 4	3
124	dust hood	1	161	extension wing	2
125	pan hd screw M5*8	4	162	tape	1
130	Main table	1	163	tape	1
131	table insert	1			


This diagram is a detailed exploded view of a mechanical assembly, likely a robotic arm or a similar actuated mechanism. It features a wide variety of components, each identified by a unique numerical label. The assembly includes a base structure (201, 202, 203, 204, 205, 206, 207, 208, 209, 210, 211, 212, 213, 214, 215, 216, 217, 218, 219, 220, 221, 222, 223, 224, 225, 226, 227, 228, 229, 230, 231, 232, 233, 234, 235, 236, 237, 238, 239, 240, 241, 242, 243, 244, 245, 246, 247, 248, 249, 250, 251, 252, 253, 254, 255, 256, 257, 258, 259, 260, 261, 262, 263, 264, 265, 266, 267, 268, 269, 270, 271, 272, 273, 274, 275, 276, 277, 278, 279, 280, 281, 282, 283, 284, 285, 286, 287, 288, 289, 290, 291, 292, 293, 294, 295, 296, 297, 298, 299, 300, 301, 302, 303, 304, 305, 306, 307, 308, 309, 310, 311, 312, 313, 314, 315, 316, 317, 318, 319, 320, 321, 322, 323, 324, 325, 326, 327, 328, 329, 330, 331, 332, 333, 334, 335, 336, 337, 338, 339, 340, 341, 342, 343, 344, 345, 346, 347, 348, 349, 350, 351, 352, 353, 354, 355, 356, 357, 358, 359, 360, 361, 362, 363, 364, 365, 366, 367, 368, 369, 370, 371, 372, 373, 374, 375, 376, 377, 378, 379, 380, 381, 382, 383, 384, 385, 386, 387, 388, 389, 390, 391, 392, 393, 394, 395, 396, 397, 398, 399, 400, 401, 402, 403, 404, 405, 406, 407, 408, 409, 410, 411, 412, 413, 414, 415, 416, 417, 418, 419, 420, 421, 422, 423, 424, 425, 426, 427, 428, 429, 430, 431, 432, 433, 434, 435, 436, 437, 438, 439, 440, 441, 442, 443, 444, 445, 446, 447, 448, 449, 450, 451, 452, 453, 454, 455, 456, 457, 458, 459, 460, 461, 462, 463, 464, 465, 466, 467, 468, 469, 470, 471, 472, 473, 474, 475, 476, 477, 478, 479, 480, 481, 482, 483, 484, 485, 486, 487, 488, 489, 490, 491, 492, 493, 494, 495, 496, 497, 498, 499, 500, 501, 502, 503, 504, 505, 506, 507, 508, 509, 510, 511, 512, 513, 514, 515, 516, 517, 518, 519, 520, 521, 522, 523, 524, 525, 526, 527, 528, 529, 530, 531, 532, 533, 534, 535, 536, 537, 538, 539, 540, 541, 542, 543, 544, 545, 546, 547, 548, 549, 550, 551, 552, 553, 554, 555, 556, 557, 558, 559, 560, 561, 562, 563, 564, 565, 566, 567, 568, 569, 570, 571, 572, 573, 574, 575, 576, 577, 578, 579, 580, 581, 582, 583, 584, 585, 586, 587, 588, 589, 590, 591, 592, 593, 594, 595, 596, 597, 598, 599, 600, 601, 602, 603, 604, 605, 606, 607, 608, 609, 610, 611, 612, 613, 614, 615, 616, 617, 618, 619, 620, 621, 622, 623, 624, 625, 626, 627, 628, 629, 630, 631, 632, 633, 634, 635, 636, 637, 638, 639, 640, 641, 642, 643, 644, 645, 646, 647, 648, 649, 650, 651, 652, 653, 654, 655, 656, 657, 658, 659, 660, 661, 662, 663, 664, 665, 666, 667, 668, 669, 670, 671, 672, 673, 674, 675, 676, 677, 678, 679, 680, 681, 682, 683, 684, 685, 686, 687, 688, 689, 690, 691, 692, 693, 694, 695, 696, 697, 698, 699, 700, 701, 702, 703, 704, 705, 706, 707, 708, 709, 710, 711, 712, 713, 714, 715, 716, 717, 718, 719, 720, 721, 722, 723, 724, 725, 726, 727, 728, 729, 730, 731, 732, 733, 734, 735, 736, 737, 738, 739, 740, 741, 742, 743, 744, 745, 746, 747, 748, 749, 750, 751, 752, 753, 754, 755, 756, 757, 758, 759, 760, 761, 762, 763, 764, 765, 766, 767, 768, 769, 770, 771, 772, 773, 774, 775, 776, 777, 778, 779, 780, 781, 782, 783, 784, 785, 786, 787, 788, 789, 790, 791, 792, 793, 794, 795, 796, 797, 798, 799, 800, 801, 802, 803, 804, 805, 806, 807, 808, 809, 810, 811, 812, 813, 814, 815, 816, 817, 818, 819, 820, 821, 822, 823, 824, 825, 826, 827, 828, 829, 830, 831, 832, 833, 834, 835, 836, 837, 838, 839, 840, 841, 842, 843, 844, 845, 846, 847, 848, 849, 850, 851, 852, 853, 854, 855, 856, 857, 858, 859, 860, 861, 862, 863, 864, 865, 866, 867, 868, 869, 870, 871, 872, 873, 874, 875, 876, 877, 878, 879, 880, 881, 882, 883, 884, 885, 886, 887, 888, 889, 890, 891, 892, 893, 894, 895, 896, 897, 898, 899, 900, 901, 902, 903, 904, 905, 906, 907, 908, 909, 910, 911, 912, 913, 914, 915, 916, 917, 918, 919, 920, 921, 922, 923, 924, 925, 926, 927, 928, 929, 930, 931, 932, 933, 934, 935, 936, 937, 938, 939, 940, 941, 942, 943, 944, 945, 946, 947, 948, 949, 950, 951, 952, 953, 954, 955, 956, 957, 958, 959, 960, 961, 962, 963, 964, 965, 966, 967, 968, 969, 970, 971, 972, 973, 974, 975, 976, 977, 978, 979, 980, 981, 982, 983, 984, 985, 986, 987, 988, 989, 990, 991, 992, 993, 994, 995, 996, 997, 998, 999, 1000). The diagram illustrates the spatial arrangement and assembly sequence of these parts, showing how they interlock and move relative to each other. Key components include a motor or

Trunnion Assembly Parts List

REF#	DERIPTION	QTY	REF#	DERIPTION	QTY
201	handwheel lock	2	272	hex bolt M10x45	1
202	handwheel	2	273	lock washer 10	1
203	set screw M5x12	2	274	flat washer 10	2
204	point 1	1	275	arbor nut	1
205	set screw M5x6	1	276	arbor flange	1
206	point 2	1	277	set screw M5x12	2
207	cap screw M6*12	1	278	arbor	1
208	lock washer 6	1	279	key 5x30	1
209	flat washer 6	1	280	bearing 6005-2Z	2
210	nut 6	4	281	collar blade arbor	1
211	point bracket	1	282	Belt pulley	1
212	pan HD screw M5*25	2	283	collar blade arbor	1
213	plate	1	284	tighten collar	1
214	pan HD screw M8*30	6	285	cap screw M5*16	3
215	lock washer 8	9	286	flat washer 5	5
216	lock pin	4	287	flat washer 5	3
217	KEY	2	288	lock nut M16*1.5	1
218	angle worm shaft	1	289	high shaft	1
219	set collar	2	290	bull gear	1
220	set screw M6x8	4	291	orientation bar	1
221	wave lock washer	2	292	roll pin 5 x 30	2
222	copper backing	4	293	cap screw M5*25	2
223	worm	2	294	gear	1
224	set screw M6x12	2	295	gear sleeve	1
225	FRONT TRUNNION	1	296	big washer	1
226	cap screw M10*30	2	297	pan HD screw M10*45	1
227	flat washer 10	2	298	lock nut 10*1.5	1
228	lock washer 10	2	299	sleeve	1

229	nut M10	2	2001	knurled knob	1
230	cap screw M6*25	3	2002	spring	1
231	washer	1	2003	pin	1
232	cap screw M8*30	1	2004	bracket	1
233	plate gear	1	2005	set screw M6x12	4
234	back bracket	1	2006	lock washer 6	3
235	left bracket	1	2007	limit collar	3
236	right bracket	1	2008	splitter tighten clip	1
237	square HD bolt	2	2009	cap screw M6*30	3
238	flat washer 8	6	2101	belt	3
239	nut M8	8	2102	motor pulley	1
240	adjust screw	2	2103	set screw M5x12	2
241	set screw M8x8	1	2104	key	1
242	Compression spring	1	2105	motor	1
243	ball	1	2106	pin	1
244	lock nut M18	1	2107	roll pin 4 X 28	1
245	high shaft	1	2108	hex bolt M12x110	1
246	hex bolt M8x30	1	2109	flat washer 12	2
247	flange casting sleeve	2	2110	lock washer 12	1
248	hex bolt M8x35	1	2111	nut M12	1
249	handwheel handle	2	2112	motor bracket	1
250	trunnion	1	2113	set screw M8x12	2
270	key 6x45	1	2114	set screw M8x30	1
271	geared bearing housing	1	2115	nut M8	1


Blade Guard Breakdown



Blade Guard Parts List

REF#	DERIPTION	QTY	REF#	DERIPTION	QTY
371	splitter	1	375	phlp HD screw M6-1×25	1
372	left guard	1	376	lock washer 6	1
373	right guard	1	377	lock washer 10	1
374	cap screw M10x30	1	378	riving knife	1


Mitre Gauge Breakdown



Mitre Gauge Parts List

REF#	DERIPTION	QTY	REF#	DERIPTION	QTY
401	mitre bar	1	418	mitre knob	1
405	mitre ring	1	419	fender washer 10mm	1
406	flat head screw m5-8*8	1	420	mitre gauge fence	1
407	mitre body pivot pin	1	421	square nut	3
408	mitre guage body	1	422	flat washer 6	4
409	mitre stop pin knob	1	423	lock washer 6	4
410	mitre stop pin block	1	424	lock level	2
411	compression sping	1	425	tighten support	1
412	mitre stop pin	1	426	lock level	1
413	cap screw m4-7*10	2	427	tighten pin	1
414	pointer miter guage	1	428	tighten clip	1
415	flat washer 4mm	1	429	lock nut 6	1
416	lock washer 4mm	1	430	set screw M8x6	2
417	phillips hd screw m4-,7*6	1	431	teflon washer	2


Fence Breakdown



Fence Parts List

REF#	DERIPTION	QTY	REF#	DERIPTION	QTY
501	cover	1	514	hex bolt M10-1.5x45	1
504	glide pad	2	515	lock nut M10-1.5	1
505	fence scale window	1	516	cam foot	1
521		1	517	magnet	1
506	set screw M12-1.75x15	4	518	cam	1
507	phlp hd screw M5-0.8x10	2	519	fence lock knob	1
508	lock washer 5	2	520	set screw M12-1.75x30	1
509	indicator	1	523	knob	3
510	special locking nut M12	5	524	teflon washer	3
511	set screw	2	525	guide bolt	3
512	hex bolt M6-1x40	1	526	fence face	1
513	lock nut M6-1	1	527	fence body	1


30" Rail & Extension Table Breakdown



30" Rail & Extension Table Parts List

REF#	DERIPTION	QTY	REF#	DERIPTION	QTY
601	guide tube insert	2	608	hex bolt 5/16-18x1-1/2	2
602	guide tube	1	609	lock washer 8	12
603	scale	1	610	flat washer 8	22
604	front rail	1	611	rear rail	1
605	cap screw M6-1x16	3	612	hex bolt M8-1.25x40	10
606	lock washer 6	3	613	nut M8-1.25	10
607	flat washer 6	3	635	extension table	1


50" Rail & Extension Table Breakdown



50" Rail & Extension Table Parts List


REF#	DERIPTION	QTY	REF#	DERIPTION	QTY
601	tube cover	2	622	foot	2
605	cap screw M6*16	5	624	phlp HD screw M8-1.25×40	6
606	lock washer 6	5	628	rear rail	1
607	flat washer 6	5	629	tube	1
608	hex bolt 5/16-18x1-1/2	2	630	scale	1
609	lock washer 8	18	631	front rail	1
610	flat washer 8	34	634	extension table	1
612	hex bolt M8x40	12	639	leg	2
613	nut 8	16			

Optional ST-1400 Sliding Table Code 104505



PART	DESCRIPTION	QTY			
201	Button HD Screw M6-1 x 12	8	213	Lock Lever M8-1.25	2
202	Lock Washer 6MM	2	214	Support Leg	2
203	Flat Washer 6MM	8	215	Hex Nut M8-1.25	2
204	Sliding Table Side Cover	2	216	Foot Pad	2
205	Sliding Table Assembly	1	217	Lock Lever Flat Washer 8MM	2
206	Cap Screw M8-1.25 x 25	3	218	Stop Plate	1
207	Lock Washer 8MM	3	219	Stop Pin Assembly	1
208	Flat Washer 8MM	3	220	Button HD Cap Screw M5-.8 x 12	4
209	Front Table Side Cover	1	221	Lock Washer 5MM	4
211	Extension Table	1	222	Flat Washer 5MM	4
212	T-NUTM8-1.25	4	223	Rear Table Side Cover	1
			224	Support Leg Washer	1

Switch Breakdown



Switch Parts List

REF#	DERIPTION	QTY	REF#	DERIPTION	QTY
701A	switch	1	711	lock washer 5	2
701D	cable	1	712	flat washer 5	2
701E	cable	1	713	chain	1
704	Switch bracket	1	714	Perforated pin	1
706	hex bolt M6x12	2	715		1
707	lock washer 6	3	716	strain relief	1
708	flat washer 6	3	717	rivet nut M5x12	4
709	Phillips screw M6x12	1	718	flat washer 5	4
710	phlp HD screw M5-.8x16	2	719	cap screw M5*20	4

1. Foreword

This instruction manual only for the table saw equipped with ST1400 & RT100.

The content includes: Product configuration and model, space requirements, the installation of switch box and the use of the guide rail.

2. Product configuration list

Options Type		Model	HW110WS	HW110WSE	HW110S-S	HW110SE-S	HW110WS-S	HW110WSE-S
Table saw	110S	/	/	●	/	/	/	
	110SE	/	/	/	●	/	/	
	HW110LG	●	/	/	/	●	/	
	HW110LGE	/	●	/	/	/	●	
Sliding table--ST1400		●	●	●	●	●	●	
Router table--RT100		●	●	Can't install	Can't install	/	/	
Rail	WS-30	●	●	●	●	●	●	
	WS-50	Optional	Optional	Optional	Optional	Optional	Optional	

NOTE:

Each table saw & attachments are equipped with independent instruction.

3. Space Requirements

Before your setup, you must insure the interspace between the machine and wall at least 800mm.

3.1 Model :HW110S-S , HW110WS-S




Fig.1

3.2 Model:HW110WS




Fig.2

4. Change the installation position of switch

When install the sliding table, you must change the installation position of the switch, you can install the magnetic switch onto the bottom of the sliding table with three sets hex bolts, as shown in **Fig.3**

M6-1x 12 hex bolts.....3

6mm lock washers.....3

6mm flat washers.....3



Fig.3

5. About Rail

Due to the installation of the sliding table, we provide the short guide, the explosion diagram and parts list of short guide, please see attachment file.

NOTE:

If the fence rails on your saw prevent is as Fig.4, you need to cut off the left ends of the rails, as Fig.4 point;

(or re-mount the rails farther to the right, which may also require you to drill new holes in your table and cut small notches into your rails for access to t-slots in your saw's table as Fig.5)

Next, you may need to re-mount the power switch to a new location, as Fig.3;




Fig.4





Fig.5

Attachment file:


WS-30"Short Rail Breakdown



WS-30"Short Rail Parts List

REF#	DERIPTION	QTY	REF#	DERIPTION	QTY
601	tube cover	2	608	hex bolt 5/16-18x1-1/2	2
602WS	tube (30")	1	609	lock washer 8	8
603	scale (30")	1	610	flat washer 8	14
604WS	front rail (30")	1	611WS	rear rail (30")	1
605	cap screw M6*16	3	612	hex bolt M8x40	6
606	lock washer 6	3	613	nut 8	6
607	flat washer 6	3			

WS-50"Short Rail Breakdown



WS-50"Short Rail Parts List

REF#	DERIPTION	QTY	REF#	DERIPTION	QTY
601	tube cover	2	610	flat washer 8	14
630	scale (50")	1	612	hex bolt M8x40	6
605	cap screw M6*16	3	613	nut 8	6
606	lock washer 6	3	628WS	rear rail (50")	1
607	flat washer 6	3	629WS	tube (50")	1
608	hex bolt 5/16-18x1-1/2	2	631WS	front rail (50")	1
609	lock washer 8	8			

The Axminster guarantee

Buy with confidence from Axminster!

So sure are we of the quality, we cover all parts and labour free of charge for three years!



For more information visit axminstertools.com/3years



The packaging is suitable for recycling.
Please dispose of it in a responsible manner.



EU Countries Only

Do not dispose of electric tools together with household waste material.
By law they must be collected and recycled separately.



Axminster Tools, Axminster Devon EX13 5PH

axminstertools.com