



TM

Timberkits Demon Dentist

CE 

(UK) Symbols in these instructions. (FR) Symboles des instructions. (ESP) Simbolos en estas instrucciones. (IT) Simboli in queste istruzioni. (Ger) Symbole in dieser anleitung



(UK) Waiting time.

(FR) Temps d'attente.

(ESP) Tiempo de espera.

(IT) Tempo d'attesa.

(DE) Wartezeit.



(UK) Wax surface to lubricate.

(FR) Appliquer la cire sur cette surface.

(ESP) Aplica la cera sobre esta superficie.

(IT) Appicare la cera su questa superficie

(DE) Wax Oberfläche zu schmieren.



(UK) Glue.

(FR) Coller.

(ESP) Pegar.

(IT) Incollare.

(DE) Leimen



(UK) Don't glue.

(FR) Ne pas coller.

(ESP) No pegar.

(IT) Non incollare.

(DE) Nicht leimen.



(UK) Glue guard. Prevents glue getting between moving parts during build. Remove after 2 minutes.

(FR) Piece de protection contre la colle. pendant l'assemblage, eviter tout dépôt de colle sur les pieces en mouvement. Enlever apres 2 minutes.

(ESP) Parte de protección de el pegamento. durante la fase de esamblaje, evitar que el pegamento se ponga sobre partes que se mueven. Quitar despues de dos minutos .

(IT) Pezzo di protezione della colla. Durante l'assemblaggio evitare che la colla vada su parti non statiche . Imuovere dopo due minuti.

(DE) Karton. Verhindert das eindringen von leim zwischen die bewegliche teile während der montage. Zwischen die beweglichen Teile.

Helpful hints/conseils utiles/consejos utiles/suggerimentutili/nützliche tipps

(UK) Check all parts present in trays
(FR) Vérifier que toutes les pièces soient présentes dans les bacs
(ESP) Controlar que hay todas las partes en la caja
(IT) Controllare tutte le parti presenti nel kit
(DE) Bitte prüfen sie, ob alle benötigten teile vorhanden sind

(UK) Read all instructions and look at all diagrams
(FR) Lire toutes les instructions et regarder toutes les figures
(ESP) Leer las intrucciones y guardar a los diagramas
(IT) Leggere tutte le istruzioni e guardare i diagrammi
(DE) Lesen sie alle anweisungen und betrachten sie die schaubilder

(UK) Check assembly before gluing
(FR) Vérifier le montage avant collage
(ESP) Controlar el montaje antes de empezar a pegar
(IT) Controllare l'assemblaggio prima di incollare
(DE) Montage prüfen vor dem einklebern

(UK) Some parts may need sanding
(FR) Certaines pièces nécessiteront d'être poncées.
(ESP) Algunas parte necesitan de ser suavizadas
(IT) Alcune parti potrebbero aver bisogno di levigatura
(DE) Möglicherweise müssen manche teile geschliffen werden

Colouring tips/conseils concernant l'application de peinture/ consejos para Pintar/ sugerimenti per colorare/lackiertipps

(UK) Do not apply paint to parts which move against one another. It is easier to paint some parts before assembling
(FR) Ne pas appliquer de peinture sur les parties qui se déplacent l'une contre l'autre. Il est conseillé de peindre avant assemblage
(ESP) No aplique la pintura sobre las partes que se tocaran. Resulta mas facil pintar las partes antes de montar.
(IT) Non applicare la pittura su quelle parti dove ce attrito con un'altra parte. è più semplice Pitturare alcune parti prima della fase di assemblaggio.
(DE) Teile, die aneinander reiben, sollten nicht lackiert werden. Fertig lackierte teile sind off leichter zu montieren

New Symbols in our Instructions



Visit our website to view instructional videos where you see this symbol.
www.timberkits.com



Pay special attention to this section.



TM

NEED ADVICE?












Luise Willis - Model Expert









There's a Timberkit human
here to help!


Or visit our website for tips, advice and instructional videos.
All these can be found in Resources/Advice Videos on our website.

www.timberkits.com












14



27
x2



26



13






12



17







35
x2





1

Patient Right Leg

**1d**

Ensure edge of part 3 lines up with part 2




2

2a




2b




Be aware that this unit will be removed later in section 4 and is only assembled here to ensure it all fits.

10mins


2c




2d



2e





7



G





3



9

4

Unit 2/3 has now been removed from assembly as mentioned in section 2





4a**4b****4c****4d**

Gently lift part #4 so that the slot engages on the 4mm x 41mm peg as shown.




5

Patient Left Leg



Ensure edge of part 3 lines up with part 2




6

6a



6b




Be aware that this unit will be removed later in section 4 and is only assembled here to ensure it all fits.

10mins


6c



6d



6e





G

7

7b


7a






7c

Place 3mm x 16mm peg in left leg assembly into top hole in part #2.




7d






Gently lift part #4 so that the slot engages on the 4mm x 41mm peg as shown.

8




9






10




Lay leg assembly down on the long edges (marked with *) of parts #10 and #11 to help line up parts #8 #10 and #11 whilst the glue dries.


11



11b





Glue in line with the angle on part #13.




15 mins

12



15mins

13






15



15mins



18

14





15

Patient Right Arm



16


Push 4mm x 28mm pegs through the hole in parts 21 by about 3mm with no glue.



Patient Right Arm


16c

Push the 4mmx28mm peg into the hole in part #19 until it is flush with the outer edge.



Patient Left Arm

16d




Push the 4mmx28mm peg into the hole in part #20 until it is flush with the outer edge.

17

17a

3mmx9mm



17b

3mmx9mm




18

Patient Right Arm


22

18a




18b

3mmx10mm




G



Patient Left Arm


23

18c




18d





3mmx10mm




G




19





19e


25




19f

Place the 3mmx9mm peg in between
the forks in part #23.


Do not glue as the arms will be glued
later in the instructions.



20



20a



28

20b

21



21a



29

30





21b


3mmx10mm





22




23



24






25



25a

Locate the 3mmx10mm pin in part #32 in the hole beneath slot in part #4. No glue.







25b




Locate the 3mmx10mm pin in part #32 in the hole beneath slot in part #4. No glue.




When completed you can pull on part #32 (on both sides) and the leg should lift up and down.

26




27






28


28a



28c




28e




37


28b




28d




29



30




30a




30c

Glue the 4mmx34mm peg into hole in middle of part #41. Apply glue in hole with a thin stick.




31

31




Round off the top edge of part #43.


32




33



34 This will give you a model that is easier for left-handed people to turn. For a right-handed model simply push the handle though the other side piece and thread on the various cams and spacers in reverse.



34a



34b




34c
G

47
(8mm deep)


34d
G

48



34e


34f




Round the edge of part
#50 with sandpaper
and then wax.

34g
G

49
(4mm deep)




Glue 2nd part #48
opposite to the other
part #48.




15mins

35





36



37

37a

Dentist Left Leg




37b

Dentist Right Leg


Glue each foot at opposite angles to each other.

38




39

Dentist Right Arm




39b


Dentist Left Arm




39c




39d



39e





39f



40


Dont push part #57 all the way down to bottom of slot.

40a**40b**


Right view




Left view


38c**41**

42




43





44




Glue part #66 in place when both feet are level on it.




45

45a




Teeth are all 3mmx10mm

45c




Sand the 3mmx10mm pegs used for the teeth to a point before gluing into holes. Pegs should be uneven for effect.

45b




Teeth are all 3mmx10mm
Sand the 3mmx10mm pegs used for the teeth to a point before gluing into holes. Pegs should be uneven for effect.





46




Remove 3mmx51mm pin from side of base and pull out all of the levers 44, 42 & 44 before proceeding to next stage.




47



48




49




Model viewed from other end.

Replace the 3mmx51mm peg back through 3mm hole at the ends of parts #44, 42,44 as before.



50




Fill with glue the 4mm hole on the end of one of the part #70's and push the 4mm x 41mm peg protruding from the part #32 above it into the glue filled hole. You might have to gently press on the top of part #4 to help with this. Wait for a short time until the glue is tacky and then slowly turn the handle until the offset cam (part #48) that is in line with what you have just glued has been in its lowest position and the 4mm x 41mm peg has been adjusted to accommodate this. The handle should be able to revolve freely with no tight spots.



Repeat this whole process with the other part #70 and part #32.

51

51a



Mark 31mm from the outer end of the head rest
and glue head in place in line with the mark.

51b



Glue lower jaw in place with a
2mm gap between the upper
jaw.

G



52


Fill hole in top of part 24 with glue (If you have superglue put a small amount in the hole before putting in the wood glue) then use a cocktail stick to really push it down into the hole whilst moving the arm up and down. Top up with more glue, re-engage the elbow pin in the fork if necessary.

**53**


54



55



Left hand



Right hand

Side view




Sand a small angle by each wrist
as shown so that the hands splay
outwards when glued in place.





Side view




56





57



57e








Remove arms and put a dab of glue inside both shoulder holes, then re-position arms in place.

Before glue dries turn handle and adjust arm position and head. The 'nod' needs to work in sync with arms.


60



- (UK) If you enjoyed building this model why not try our others. Available directly from Timberkits Ltd or from our UK, European or worldwide retail partners. Check our website to find your nearest stockist.
- (FR) Si vous avez apprechie construire ce modele, pourquoi ne pas en essayer d'autres. Ils sont disponibles chez Timberkits Ltd ou chez nos partenaires detaillants au Royaume Uni, en Europe et plus largement dans le monde.
- (SP) Si te has divertido con este modelo, porque no pruebas los ademas. Estan todos disponibles directamente desde Timberkit Ltd o desde las nuestras tiendas en Reino Unido, Europa o en otros continentes. Visita el nuestro sitio web para conocer el punto vendida mas cercano.
- (IT) Se ti sei entusiasmato a costruire questo modello, perche non provare gli altri. Sono disponibili direttamente dalla Timberkits Ltd oppure dai nostri rivenditori in Gran Bretagna, Europa e altri continenti. Visita il nostro sito web per trovare il più vicino punto vendita.
- (DE) Wenn sie freude daran hatten, dieses modell zu bauen, wieso nicht die anderen ausprobieren. Sie können direkt bei Timberkits Ltd bestellen oder bei unseren handelspartnern in Großbritannien, Europa und weltweit. Besuchen sie unsere website für ihren nächstgelegenen händ-ler.

www.timberkits.com





Timberkits Limited
Old Village Hall
Llanbrynmair
Powys, SY19 7AA
00 (44) (0) 1650 521635
timber_kits@btconnect.com
www.timberkits.com

Timberkits logo and all Timberkits designs are Copyright (©) 2012 all rights reserved.