PROJECT PEN KITS





For more info and



Bushing Set:

953310

Drill Bit Size: 27/64"

Minimum Blank Size

19 mm x 19 mm x 80 mm

PREPARING THE BLANKS, HINTS & TIPS

Preparing a wooden or acrylic/polyester blank for a pen mandrel.

Venetian Twist Pen Kit - Platinum

- 1. Cut a blank to the length of the tube plus approximately 2.5mm to allow for trimming and squaring off the ends.
- 2. Mark the centre on the end of the blank.
- 3. Using the recommended drill bit, drill a hole lengthwise through the blank.
- 4. Apply epoxy glue, Polyurethane glue or gap filling cyanoacrylate (super glue) to the tubes.
- 5. Insert the tube into the blank with a twisting motion to spread the glue evenly inside the hole.

- 6. Centre the tube lengthwise inside the
- 7. Allow the adhesive to cure.
- 8. When cured, square the ends of the blank. Using a barrel trimmer with a guide matching the inner diameter of the tube or a universal pen blank squaring jig with a disc sander.
- 9. Take the excess material down flush with the ends of the brass tube. (do not trim beyond the length of the tube since this may interfere with operation of the mechanism and assembly).

Tips/Hints

- Excessive pressure may cause the drill bit to wander and/or split the blank. Slow the feed rate and back the drill bit out repeatedly for chip removal.
- Roughen the brass tube slightly with abrasive for better adhesion.
- Certain acrylic blanks are more transparent than others, especially lighter colors or blanks with light colored swirls. To avoid the risk of the brass tube showing through the pen blank, paint the tubes white or black before gluing them in.
- The barrel trimmer guide also cleans any adhesive that may have gotten inside of the tube.

TURNING THE BLANK, HINTS & TIPS

- 1. Mount the bushings and blank onto a pen mandrel according to the diagram.
- 2. Secure the bushings and blank onto the mandrel.
- 3. Slide the tailstock with a live centre into place against the mandrel and lock in position. This is for support; only slight pressure is required.
- 4. Using sharp tools, turn the blank down to become the Pen Barrel with the profile of your choice.
- 5. Turn the blank very slightly oversize, then sand and polish the ends down to the same diameter as the bushings.
- **6.** Using successively finer abrasives gradually sand and polish the Pen Barrel.
- 7. Finish the Pen Barrel with your preferred choice of polish.

Tips/Hints

• Don't be afraid to sharpen frequently especially when turning acrylics.



ASSEMBLY, HINTS & TIPS

- 1. Layout parts according to diagram A.
- 2. Before assembling the pen, take the twist mechanism assembly out of the bag and gently twist the end back and forth to lubricate the mechanism.
- **4.** Make sure the brass thread is screwed tight against the threaded tube.

WARNING! TWIST THE BRASS THREAD NOT THE TWIST MECHANISM OTHERWISE THE MECHANISM MAY BREAK!

- **5.** Press the Finial/Clip Assembly into one end of the Pen Barrel.
- **6.** Insert the Refill into the Nib Assembly making sure that the Spring is in place.
- **7.** Screw the Twist Mechanism over the Refill and into the Nib Assembly.
- **8.** Slide the Pen Barrel/Finial/Clip Assembly over the Twist Mechanism.
- **9.** A single twist is all that is required to operate the pen.

Tips/Hints

- Use a woodworking vice, one handed bar clamp, arbor press or a dedicated pen press.
- Press parts together slowly and steadily
- When pressing the parts together, CHECK the parts are correctly aligned with each other and straight. If the part is crooked or misaligned, it will result in a poor fit or render the pen unuseable.
- When laying out your pen barrel with the parts, pay careful attention to keep the pen barrels in the same orientation as when on the mandrel. i.e. a pen barrel may have a "top" and "bottom", now is the time to be certain of the orientation.

DIAGRAM A



Visit the Knowledge blog 'How To Make A Pen' for hints, tips and videos



Axminster Tools, Axminster, Devon, EX13 5PH

A X M I N S T E R T O O L S . C O M